




# Building an IoT Temperature Sensor

Liam Osman


## GitHub Link:

- These presentation slides
- Firmware code for reference



# What are we building today?

Your IoT board will be able to measure temperature and humidity!



**Variables** ↻

✓ humidity (double) = <b>43</b>	Get
✓ temperature (double) = <b>18</b>	Get

# Workshop Stages:

1. Unbox and set up physical components
2. Register for and set up Particle account
3. Coding firmware and flashing to device




# Physical Components



# Unpack Components Needed


- Breadboard
- USB cable
- Argon Board
- DHT11 sensor
- Jumper Wires
- Wireless antenna






# Attaching the Antenna

Snap coaxial cable onto "WiFi"






# Breadboard Diagram





=







# Placing into the Breadboard

- Anywhere theoretically works
- Example put in the upper right corner
- May take a bit of force to insert




# Placing the DHT11 Sensor

- 3 pins on DHT11 sensor board used today
- Place sensor away on different row from Argon
- The back of the board has built-in resistors






# Plug in Board to Laptop






# Connecting Jumper Wires

Link the jumper cables on the same numbers as pins to connect them

Argon Board		DHT11 Sensor	
Pins	Bread board	Pins	Bread board
3.3	2	+	28
A1	6	Out	29
	4	-	30





# Account Setup

# Particle Setup


1. Press "Get started"
2. Create a "Personal" account
3. "Get started" again
4. Start setting up my device
  - "Device with USB port"





# Particle Setup

1. Press "Select device"
2. Connect Argon
3. Update device
  - Should go into DFU mode
4. Continue



# Particle Setup

1. Use Personal Sandbox
2. Make a new product
3. Add to product
4. Give device a name or just keep default

Select your organization \*

Personal Sandbox

Select a product within your organization \*

AirReader

[Or create a new product](#)

Give your device a name


Name your device \*

hamster\_hare

Use underscores instead of spaces

# Particle Setup

1. Start a mobile data hotspot (or use a neighbor's)
  - We can't connect to University WiFi!
2. Connect to your hotspot network
  - This can take a minute
3. Press "Go to console"







**Firmware**

# Particle Web IDE

1. From the console, open the web IDE
2. Give your App a name
3. Delete all contents

Current App

*Optional description*


Web IDE



# Importing a library

1. Open "Libraries" on the bottom left of the IDE
2. Search for PietteTech\_DHT
3. Press it and include into your app

*Libraries*



# Constants

```
3 // Include a sensor library for DHT11
4 // This one was created by Scott Piette
5 // Remember to "Include in Project"
6 #include <PietteTech_DHT.h>
7
8 // Constant Declarations
9 #define DHT_TYPE          DHT11
10 #define DHT_PIN           A1
11 #define DHT_SAMPLE_INTERVAL 2000
```



# Instantiations

```
13 // Instantiate a DHT sensor object of our type
14 PietteTech_DHT DHT(DHT_PIN, DHT_TYPE, dht_wrapper);
15 // DHT wrapper function necessary for object
16 void dht_wrapper() { DHT.isrCallback(); }
17
18 // Declare variables on board memory
19 double temperature = 0;
20 double humidity = 0;
```

# Setup



```
22 // Setup runs only once when board is started
23 void setup() {
24
25     // Connects variables to Particle cloud data
26     Particle.variable("humidity", humidity);
27     Particle.variable("temperature", temperature);
28
29     // Starts our sensor object behavior
30     DHT.begin();
31 }
```

# Loop

```
33 // Runs forever while device is on
34 void loop() {
35
36     // DHT sensor can only acquire new value
37     // once every interval, so this prevents
38     // updating every loop cycle of device
39     if (!DHT.acquiring()) {
40
41         // update variables with methods
42         humidity = DHT.getHumidity();
43         temperature = DHT.readTemperature();
44     }
45 }
```

# Flashing


- Verify compiles your firmware
- Flash programs your board
- May take a minute or two





# Console

Navigate back to the console, and open your product and device




# Reading Results

1. Scroll down to find the "Variables" box
2. Press "Get" to read your sensor!

*Homework Challenge:*

Can you make it output Fahrenheit?

Try looking into our imported library



# Follow Us



Instagram



LinkedIn



Discord